



## 8 FM antenna Select models only

FM signal to computer  
调频天线 (仅适用于部分型号)  
将调频信号接入电脑



## 9 Power Connection


Computer to electrical outlet  
Grounded connection or connection to surge protector is recommended  
连接电源  
将电脑连接到电源插座  
建议接地或连接电涌保护器。




## 10 Modem / LAN

调制解调器/ LAN

Connect modem cable to computer.  
Select models only.  
将调制解调器电缆连接到电脑，  
仅适用于部分型号。




OR  
或者






## 11 Power On

开机



Turn on monitor, computer, and sound system.  
打开显示器、电脑，再打开声音系统。

Your PC may look different from the ones shown here. Component, connector location, type, and number vary by model.  
您的电脑外观可能与此处图示有所不同。电脑中的组件、接口的位置、类型和数目会因型号而异。



### China only — 仅适用于中国

#### 激活 Windows XP

您必须在试用期内激活 Windows XP，否则，试用期结束后将无法继续使用 Windows XP。  
您可以通过 Internet 或电话激活 Windows XP。激活 Windows XP 的方法是：

- 1 单击“开始”，选择“所有程序”，然后单击“激活 Windows”。
- 2 按屏幕上的说明进行操作。您必须输入电脑的 Windows XP 标签上的 25 位产品密钥号。

注意：执行“系统复原”或“系统还原”之后，必须重新激活 Windows XP。